
ChE 333 Transport Phenomena III, fundamentals of Mass Transfer Studio Worksheet #4 Liquid diffusion

NAME				
Studio Section	Studio	Studio	Studio	Studio
Studio Section	12:00-12:50	13:00-13:50	14:00-14:50	15:00-15:50

Instructions: Open book, notes, and homework. Make sure to write your name and studio on any additional sheet of paper with your solution. Show your calculation, and algebraic setup, and make sure to include units. Please turn in your studio at the end of class.

Characterization of Equine Synovial Fluid – Separation of Macromolecules

For several years the *CBEE Polymer Characterization Laboratory* has been involved with the Dr. Jill Parker of the *OSU School of Veterinary Medicine* on a project to characterize the molecular and rheological properties of equine synovial fluid. Synovial fluid is primarily responsible for the lubrication of most equine and human articular joints (knee and hip joints). Synovial fluid is composed of phosphate buffer solution (PBS), low molecular weight species (immunoglobulins), proteins, and a very large polymer molecule called *Hyaluronic Acid (HA)*, which is primarily responsible for lubrication. *Size Exclusion Chromatography* (SEC) is used to characterize the molecular properties of synovial fluid and determine the size of the proteins and hyaluronic acid. SEC utilizes a packed column of semi-permeable gel particles (*Gel Permeation Chromatography*) to separate macromolecules and here we are mainly interested in separating the *protein* and the *hyaluronic acid*.



As a first-pass approximation, you may assume that the gel particles have *cylindrical 45 nm pores*.

GPC is always run at very dilute conditions.

Temperature = 20 C (293 K)

Hyaluronic Acid (HA): Mw = 500,000 Daltons (g/gmole), d_s = 18nm

Protein (P): $Mw = 80,000 \text{ Daltons}, d_s = 8nm$

Solvent: Phosphate Buffer Solution (PBS) (relative viscosity = 1.15 - compared to water at same T)

The viscosity of water = $9.90 \times 10^{-4} \text{ Pa s or } 0.990 \text{ cP}$

Boltzmann const: $\kappa = 1.38 \times 10^{-23} \text{ J/K}$, $[1 \text{ J} = 1 \text{ Pa-m}^3 = 1 \text{ kg-m}^2/\text{sec}^2]$ *Assumptions:* Protein and HA may be considered rigid spheres at infinite dilution, and molecular diffusivity can be calculated using the Stokes-Einstein equation.

a) Sketch the process and state assumptions.

ChE 333 Transport Phenomena III, fundamentals of Mass Transfer Studio Worksheet #4 Liquid diffusion

protein and HA in
and the using the GPC